



HOW TO USE... SMALL GUY WEB, SINGLE WINCH


1. Insert stake into ring end of web. On opposite end, snap onto plate at tent. Leave slack in web for placing poles in position.



2. Raise poles as directed in product assembly instructions leaving slack in web.




3. When pole is in correct position, release latch and hand pull all slack from web. Then tighten web with winch. **SEE NOTE #1**



NOTE #1: Do not overfill winch drum. Overfilling winch drum will interfere with release mechanism.

4. When winch is fully opened (handle against web) web can be loosened or tightened as required. To tighten lift latch and move winch handle forward. This motion causes web to wrap around drum.

SEE WARNING
on reverse side of
this page.



1100 Burch Dr., Evansville, IN 47725
Ph. 812-867-2421 • Fax 812-867-0547
E-mail: tents@anchorinc.com • www.anchorinc.com

Quality, Craftsmanship and Service Since 1892.
Copyright © Anchor Industries 2001



Thank you for purchasing an Anchor product. In return, we pledge Quality, Service and Craftsmanship and are available for any questions you may have or assistance you may need.

PHONE NUMBER

812-867-2421

FAX NUMBER

812-867-0547

Anchor products are of superior design and operate best within the parameters of these instructions. It is **IMPERATIVE** that the instructions be carefully read and **COMPLETELY FOLLOWED**.

WARNING

1. Use for tensioning tent products only.
2. Do not use if webs are worn or threads are broken.
3. Do not over-tension.
4. Follow assembly instructions for safe use.

* See product assembly instructions for proper tensioning.